# **CANOPY CAMPER**

To suit mid-size pickups

#### **AVAII ABI F FOR**

### **DOUBLE CAB**

To suit Ford Ranger (2012 – 2021)
To suit Ford Ranger (2022+)
To suit Isuzu Dmax (2012 – 2019)
To suit Isuzu Dmax (2020 – Present)
To suit Mercedes Benz X-Class (2017 – Present)
To suit Nissan Navara NP300 Europe (2016 – 2020)
To suit Nissan Navara NP300 ZA/AUS (2016 – 2020)
To suit Toyota Hilux (2005 – 2015) (Vigo)

To suit Toyota Hilux (2015 – Present) (Revo)
To suit VW Amarok (2010 – 2022)

To suit VW Amarok (2023+)

To suit Toyota Land Cruiser 79 OEM Double Cab To suit Jeep Gladiator (2019 – Present) DC

#### **EXTRA CAB**

To suit Ford Ranger (2012 – Present)
To suit Toyota Hilux (2005 – 2015) (Vigo)
To suit Toyota Hilux (2015 – Present) (Revo)
To suit Isuzu Dmax (2020 – Present)

### LONG BED or SHORT BED

To suit Chevrolet Colorado USA (2015 – Present) DC
To suit Toyota Tacoma (2005 – 2015) (Gen2) SB
To suit Toyota Tacoma (2005 – 2015) (Gen2) LB
To suit Toyota Tacoma (2016 – Present) (Gen3) SB
To suit Toyota Tacoma (2016 – Present) (Gen3) LB
To suit Ford Ranger USA (2019+) SB + LB
To suit Nissan Frontier (2022+) DC

#### SINGLE CAB

To Suit Toyota Land Cruiser 79 SC

\* Fitment is filler kit specific

#### DIMENSION

DRY WEIGHT: (Basic shell) 210kg

FULLY KITTED WEIGHT: 250kg (approximately)

General Drawings of all units can be found on alu-cab.com

Available in the BASIC or DELUXE model

#### BASIC UNIT:

A shoe bag fitted on the roof
One light on the roof
One light under the bed
Three lights at the doors
Two stalk lights
USB port in the bed section
Wiring for solar panel (excludes the solar panel)

### **DELUXE UNIT:**

A shoe bag fitted on the roof
One light on the roof
One light under the bed
Three lights at the doors
Two stalk lights
USB port in the bed section
Wiring for solar panel (excludes the solar panel)
Canvas Mesh bags @ rear panels
Canvas bags at the rear door
Set of 2 Molle Plates.
Shadow Awning and Awning deflector (fitted)



Molle Plate, Side Door Grid, Mozzie Net Sets, Spare Wheel

Bracket available as additional accessories for both models

### MOLLE PLATE & FIREPLACE MOLLE PLATE

- Accessory mounting plate that can be added to the rear of your canopy camper

- It can be used to mount a gas bottle, our infamous can crusher, jerry can holder
- The Fireplace Molle Plate is d esigned around the Dickinson P9000 Heater



### SIDE DOOR GRID

- D esigned to fit on the inside of the Canopy Camper side doors
- Simple installation process
- Mounting area for additional recovery/overland or kitchen gear



### MOZZIE/MIDGE NETS

- Essential for the Canopy Camper side doors and rear door
- Keeps bugs and insects out of your vehicle while allowing fresh air inside
- Designed with a heavy-duty canvas cover, which can be rolled up, exposing the netting material only

## **SPARE WHEEL BRACKET**

- Has a multi stud universal PCD layout to fit all OEM wheel holes
- Features an adjustable section that can fit various wheel offsets and gives you the ability to tighten the wheel against the wheel carrier
- This clamping feature allows the wheel to be securely held in place and removes any vibrations