



FITMENT INSTRUCTIONS

TOYOTA TUNDRA 5,5ft & 6,5ft

Installation Instructions

Preliminary information

Installation and fitment instructions includes the tools required, fasteners included in the kit, and the hardware included in the kit.

Please follow the instructions and check installation steps with the images in this document.

Alu-Cab recommends that all sealing work is allowed to cure for 24 hours, after which you may drive the vehicle on normal paved roads. Before driving off-road with your Alu-Cab product or operating your roof conversion, an additional cure period of 48 hours is required.

Failure to follow these instructions will void your warranty. Please ensure that you follow the sealant manufacturers curing time as per their technical data sheet.

These times may differ slightly from the times we have recommended.



Service Enquiries email
queries@alu-cab.com

DISCLAIMER

Safety Notice – Lifting and Handling of Product


Do not attempt to lift, move, or suspend the canopy, canopy camper, or any related product using eyebolts, eye nuts, or any components attached to the cargo rails or roof accessory tracks.

These points are not engineered or rated for lifting loads and may result in serious injury, product damage, or failure if used.

For all lifting and handling operations, only use approved lifting methods such as:

- A forklift positioned securely beneath the base structure, or
- Outrigging poles attached to the designated lifting brackets supplied or approved by Alu-Cab.

Always ensure lifting equipment and methods comply with applicable safety standards. Improper lifting may void the warranty on this product.



Service Enquiries email
queries@alu-cab.com

Installation Instructions

Tools and Consumables Required for Installation of the Canopy Camper

1.1

Tools

TOOL	APPLICATION
Ratchet	Used to tighten down fasteners
13mm Ring Flat Spanner	Used to tighten M8 fasteners
19mm Ring Flat Spanner	Used to tighten M12 fasteners
T-40 Spline Socket	Used to remove OEM Bolts
5mm Allen Key Socket	Used to tighten M8 button-heads
13mm Socket	Used to tighten M8 fasteners
19mm Socket	Used to tighten M12 fasteners
Square Extension	Used with ratchet


1.2

Consumables

CONSUMABLES	APPLICATION
Black UV 521 sikaflex	Used to seal the Canopy Camper once installed
Rags	Used to clean up after install

Installation Instructions

Mounting and Filler Kit Component Identification




ITEM NO.	PART NUMBER	Revision	DESCRIPTION	QTY
1	CC-FK-TUN22-A01	00	TUN22 REAR FILLER KIT ASSEMBLY	1
2	CC-FK-TUN22-A02	04	TUN22 MOUNTING BRACKETS MAIN ASSEMBLY	1
3	165-TUNDRA-FNT-FLLR-KIT-ASSY-01	02	TUNDRA FRONT FILLER KIT ASSEMBLY	1

Installation Instructions

Rear Filler Kit - Component Identification

The Rear Filler Assembly is made up of three main sheet metal parts, the inside boxes as well as the bottom filler bracket. Begin by removing the tailgate in preparation.




ITEM NO.	PART NUMBER	Revision	DESCRIPTION	QTY
1	CC-FK-TUN22-P001	00	TUN22 RIGHT FILLER BOX	1
2	CC-FK-TUN22-P002	00	TUN22 LEFT FILLER BOX	1
3	CC-FK-TUN22-P003	00	TUN22 BOTTOM SUPPORT PLATE	1
4	CC-FK-TUN22-RUB-BS-(150mm)	00	RUBBER	2
5	CC-FK-TUN22-SPNG-RUB-1020 (1500)	00	1020 SPONGE RUBBER (1500MM)	1
6	CC-FK-TUN22-SPNG-RUB-1025 (400)	00	1025 SPONGE RUBBER (400MM)	2
7	CC-FK-TUN22-RUB-BS-(80mm)	00	BS RUBBER (80MM)	2
8	HEX-M8x20		M8x20 HEX BOLT S/S	21
9	FFW-M8		M8x20mm OVERSIZED WASHER S/S - DIN 9021	29
10	NCAP-M8		NUT CAP-08mm	29
11	NY-M8		M8 NYLOC NUT S/S	21
12	HEX-M8x30		M8x30 HEX BOLT S/S	2
13	SW-M8		M8 SPRING WASHER S/S	2
14	PW-M10X30	00	PLASTIC WASHER (NYLON) - (ID-10mm ; OD-30mm ; 2.5mm THICK)	2

Installation Instructions

Rear Filler Kit – Installation

The OEM bolts as indicated below need to be removed along with the tailgate before the rear filler kit can be installed. Ensure the bolts are kept in a safe location so that they are not lost as they will be required in a later part of the installation.



Installation Instructions


Rear Filler Kit - Assembly

The rear filler kit needs to be assembled in the correct order. The below image indicates steps one through to three for assembling this kit

1-FIT BOTTOM SUPPORT BRACKET TO VEHICLE AND FASTEN DOWN USING THE OEM BOLTS FOR THE HINGE POINT


3-SLIDE BOXES INTO PLACE USING BOLTS SHOWN AND TIGHTEN NUTS ON THE INSIDE ONCE IN THE CORRECT POSITION.

2-MOUNT LOWER DOOR FRAME.



Installation Instructions

Rear Filler Kit - Assembly






OEM bolts removed earlier. Please ensure the bolts securing the Tail-lights are reinstalled as well



Installation Instructions

The front filler is composed of 3 separate parts and is only required if the vehicle is of the 6.5ft variety. Skip ahead to the installation of the base unit if you are installing the 5.5ft variety (page 9).


The front filler is fitted to the camper directly before mounting the camper on the Load bin. Slide the bolts indicated in the drawing into the bottom nut slot of the frame and line them up with the slots cut into the bracket. Fasten the bracket down using a washer and nylock nut. Lastly apply Black Sikaflex to the front ensuring a weatherproof seal. The left and right brackets can then be installed adding some rigidity to the entire assembly



Installation Instructions

3

Rear Filler Panel Assembly:



ITEM NO.	PART NUMBER	DESCRIPTION	QTY
1	165-RAM-FNT-RHS-FIL-BRK-01	FRONT RHS FILLER BRACKET	1
2	165-RAM-FNT-LHS-FIL-BRK-01	FRONT LHS FILLER BRACKET	1
3	165-TUNDRA-FNT-BOT-FIL-BRK-01	FRONT BOTTOM FILLER BRACKET	1
4	165-TUNDRA-FNT-LHS-FIL-BRK-01	RIGHT FRONT FILLER BRKT	1
5	165-TUNDRA-FNT-RHS-FIL-BRK-01	RIGHT FRONT FILLER BRKT	1
6	HEX-M8x16	M8x16 HEX BOLT S/S	4
7	HEX-M8x20	M8x20 HEX BOLT S/S	5
8	BHD-M8x16	M8x16 B/HD BOLT S/S	4
9	NY-M8	M8 NYLOC NUT S/S	13
10	NUT-M8	M8 HEX NUT S/S	4
11	FW-M8	M8x16mm FLAT WASHER S/S - DIN 125	4
12	FFW-M8	M8x20mm OVERSIZED WASHER S/S - DIN 9021	17
13	SW-M8	M8 SPRING WASHER S/S	4


Installation Instructions

Canopy Camper Base Unit - Installation & Assembly

Seating the Base Unit

Attach the gasket material to the lower seating surface of the Canopy Camper's base frame - Refer to the stand-alone Fitment Instruction for this process.


Lower the Canopy Camper Base Unit onto the already mounted Rear Filler Assembly, as shown in the image above, and align the lower and upper portions of the door frame.



Installation Instructions


Base Unit to Rear Filler Assembly Connection

Using the supplied hardware, fasten the lower and upper door frames together, on each side of the **EXTERNAL** door opening. See images below:




Installation Instructions

Using the supplied hardware, fasten the lower and upper door frames together, on each side of the **INTERNAL** door opening. See images below:



Installation Instructions


Mounting Bracket Kit - Component Identification



ITEM NO.	PART NUMBER	Revision	DESCRIPTION	QTY
1	TT-NUT-PLT-01	1	NUT PLATE	6
2	HEX-M8x30		M8x30 HEX BOLT S/S	18
3	SQN-M8x30		M8x30 CUP SQ BOLT S/S	12
4	NY-M8		M8 NYLOC NUT S/S	30
5	FFW-M8		M8x20mm OVERSIZED WASHER S/S - DIN 9021	12
6	FW-M8		M8x16mm FLAT WASHER S/S - DIN 125	18
7	NCAP-M8		NUT CAP-o8mm	30
8	ELAS-BAND-14		ELASTIC BAND NO.6	6
9	CC-FK-TUN22-P004	2	TUN22 MOUNT BRACKET	6
10	CC-FK-TUN22-P005	0	TUN22 MOUNT BRACKET SPACER	12
11	BX-BB		BRACKET - BOX	1

Installation Instructions

Mounting Bracket Kit - Component Identification



ITEM NO.	PART NUMBER	Revision	DESCRIPTION	QTY
1	CC-FK-TUN22-P004	2	TUN22 MOUNT BRACKET	1
2	CC-FK-TUN22-P005	0	TUN22 MOUNT BRACKET SPACER	2
3	TT-NUT-PLT-01	1	NUT PLATE	1
4	HEX-M8x30		M8x30 HEX BOLT S/S	3
5	SQN-M8x30		M8x30 CUP SQ BOLT S/S	2
6	NY-M8		M8 NYLOC NUT S/S	5
7	FFW-M8		M8x20mm OVERSIZED WASHER S/S - DIN 9021	2
8	FW-M8		M8x16mm FLAT WASHER S/S - DIN 125	3
9	NCAP-M8		NUT CAP-08mm	5
10	ELAS-BAND-14		ELASTIC BAND NO.6	1

Installation Instructions

Mounting Bracket Kit – Installation Part 1


Side Mounting Brackets

The side mounting brackets are installed in two parts. Firstly, put together the nut plate assembly.


This can be done by inserting two cup squares into the nut plate (TT-NUT-PLT-01). With the cup square inserted secure it in place using the provided elastic by stretching it over the back of the plate.

The next step is to slide the nut plate assemblies into the rail system on the Tundra.

Place one nut plate assembly in the front of the load bin, one in the middle and one in the rear. Repeat this on the other side of the bin with the other rail.



Nut Plate Assembly



Installation Instructions

Mounting Bracket Kit – Installation Part 2


Side Mounting Brackets

To install the second part of the side mount brackets (CCC-FK-TUN22-P004) firstly slide 2 off M8 bolts into the Canopy Camper Frame per bracket set, therefore 6 off bolts will need to slid into the frame per side.

Align these M8 bolts with the nut plate assemblies, and slide the CCC-FK-TUN22-P004 over the bolts as shown in the image below.

Add washers and nylock nuts to both the bolts in the Canopy Camper frame and the cup square in the mounting rail, effectively pulling the CCC-FK-TUN22-P004 onto both frames.


Fasten all the nylock nuts down until they are tight and install the plastic nut caps to finish off the installation of the mounting brackets.



Installation Instructions

Rear Door Rebate Installation


Insert the Rear Door Rebate Frame into the door frame opening, ensure that mounting holes all align. Using the supplied hardware, rivet the frame in place along the LHS, RHS and upper and lower mounting interfaces. See images below:



Installation Instructions

Rear Door Installation

The Rear Door Assembly is supplied fully assembled with its hinges, and the locking mechanism, as shown below:




Installation Instructions

Insert the assembled door into the rear door opening. Fasten the four (4) hinges into the nut slot on the RHS door frame first, using the supplied hardware.

Align the two (2) locking mechanism Hook Brackets with the upper and lower lock tabs and fasten into the nut slot on the LHS frame, using the supplied hardware.

Installed Rear Door shown below (rear Filler Assembly removed for clarity):



NB! The Canopy Camper must rest solely on the mounting brackets and no load is allowed on the load bin. Once this is completed, the Canopy Camper has been installed successfully.

Installation Instructions

Installation Completed

Your installation of the Tundra Canopy Camper is now completed.

Congratulations!

Please remember that any areas where there is Sikaflex might still be sticky and should cure for a minimum of 24 hours before going on any overlanding trip.

From us at the Alu-Cab Team:

Happy Camping!

Disclaimer

All rights reserved. No part of this website may be reproduced, translated, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without prior written permission of the owner.

Review all instructions information carefully before installation.

Any damages, direct or incidental to the installer and/or property due to incorrect installation of any parts are the responsibility of the installer. Due to the various applications and fitment options available, the responsibility lies with the user to ensure all mounting points are secure and tight before every trip.

If unsure, consult with your Distributor regarding the operations of our products.

Users are advised to be mindful of the load they are carrying and drive in accordance with road conditions.

WARNING

Always wear appropriate PPE (Personal protection equipment) when fitting our products. Although the mounting kit is designed to be DIY, if you have any doubts or concerns, contact an accredited fitment centre to carry out the work. Alu-Cab will not be liable for any injury to persons, and/or damage to products and/or vehicles.

While Alu-Cab Holdings takes reasonable measures to ensure that the contents of this Website are accurate and complete, Alu-Cab Holdings makes no representations or warranties, whether express or implied, as to the quality, timeliness, operation, integrity, availability or functionality of this Website or as to the accuracy, completeness or reliability of any information on this Website. Alu-Cab Holdings reserves the right to make changes, corrections and/or improvements to the information and to the products and programs described in such information, at any time without notice.

Alu-Cab Holdings will use reasonable endeavours to maintain the availability of the Website, except during scheduled maintenance periods, and reserves the right to discontinue providing the Website or the service or any part thereof with or without notice to you. Any person who accesses this Website or relies on this Website or on the information contained in this Website does so at his or her own risk.

Occasionally, at our discretion, we may include or offer third-party products or services on our website. These third-party sites have separate and independent privacy policies. We therefore have no responsibility or liability for the content and activities of these linked sites. Nonetheless, we seek to protect the integrity of our site and welcome any feedback about these sites.