

Alu-CabTM

OPERATING INSTRUCTIONS



OPENING



STEP ONE:

Release the locking mechanism on both sides of the table.



STEP TWO:

Guide the table downwards and towards you.



STEP THREE:

Flip the table top down.



STEP FOUR:

Adjust height and angle using the straps on either side.



CLOSING



STEP ONE:

Flip the table top up.



STEP TWO:

Guide the table upwards and force it towards the vehicle.



STEP THREE:

Secure the locking mechanism on both sides of the table.