



FITMENT INSTRUCTIONS

GM SILVERADO 1500 CHEVROLET SIERRA 1500 5,5ft and 6,5ft
[2007 TO 2018] Canopy Camper and ModCAP Camper

Installation Instructions

Preliminary information

Installation and fitment instructions includes the tools required, fasteners included in the kit, and the hardware included in the kit.

Please follow the instructions and check installation steps with the images in this document.

Alu-Cab recommends that all sealing work is allowed to cure for 24 hours, after which you may drive the vehicle on normal paved roads. Before driving off-road with your Alu-Cab product or operating your roof conversion, an additional cure period of 48 hours is required.

Failure to follow these instructions will void your warranty. Please ensure that you follow the sealant manufacturers curing time as per their technical data sheet.

These times may differ slightly from the times we have recommended.



Service Enquiries email
queries@alu-cab.com

DISCLAIMER

Safety Notice – Lifting and Handling of Product


Do not attempt to lift, move, or suspend the canopy, canopy camper, or any related product using eyebolts, eye nuts, or any components attached to the cargo rails or roof accessory tracks.

These points are not engineered or rated for lifting loads and may result in serious injury, product damage, or failure if used.

For all lifting and handling operations, only use approved lifting methods such as:

- A forklift positioned securely beneath the base structure, or
- Outrigging poles attached to the designated lifting brackets supplied or approved by Alu-Cab.

Always ensure lifting equipment and methods comply with applicable safety standards. Improper lifting may void the warranty on this product.



Service Enquiries email
queries@alu-cab.com

Installation Instructions

Canopy Camper Fitment – Tools, Fasteners & Hardware

1.1

Tools & Items Required

Tool	Application
Ratchet	Used to tighten down fasteners
13mm Ring Flat Spanner	Used to tighten M8 fasteners
19mm Ring Flat Spanner	Used to tighten M12 fasteners
T-40 Spline Socket	Used to remove OEM Bolts
5mm Allen Key Socket	Used to tighten M8 button-heads
13mm Socket	Used to tighten M8 fasteners
19mm Socket	Used to tighten M12 fasteners
Square Extension	Used with ratchet

1.2


Consumables

Consumable	Application
Black UV 521 Sikaflex	Used to seal the Canopy Camper once installed
Rags	Used to clean up after install

Installation Instructions

Canopy Camper Fitment – Tools, Fasteners & Hardware

1.3




ITEM NO.	PART NUMBER	DESCRIPTION	QTY
1	165-GM07-CC-RER-FLLR-ASSY-01	REAR FILLER ASSEMBLY	1
2	165-GM07-CC-MNT-ASSY-01	MOUNT ASSEMBLY	1
3	CC-FK-GM19-A02	FRONT FILLER ASSEMBLY	1

Installation Instructions

2.

Rear Filler Kit - Component Identification

The Rear Filler Assembly is made up of three main sheet metal parts, the inside boxes as well as the bottom filler bracket.




ITEM NO.	PART NUMBER	DESCRIPTION	QTY
1	165-GM07-CC-RER-BOT-COV-PLT-01	REAR BOTTOM COVER PLATE	1
2	165-GM07-CC-INNERBOX-LH-01	INNERBOX RIGHT HAND SIDE	1
3	165-GM07-CC-INNERBOX-RH-01	INNERBOX RIGHT HAND SIDE	1
4	HEX-M8x20	M8x20 HEX BOLT S/S	23
5	NY-M8	M8 NYLOC NUT S/S	23
6	FFW-M8	M8x20mm OVERSIZED WASHER S/S - DIN 9021	29
7	NCAP-M8	NUT CAP-08mm	29
8	SPNG-RUB-1025 - (528)	SPONGE RUBBER - 10X25mm (10m p/roll)	2
9	SPNG-RUB-1025 - (1320)	SPONGE RUBBER - 10X25mm (10m p/roll)	1

Begin the installation of the canopy camper by removing the tailgate and all the OEM bolts that are in the space where the tailgate seats into the load bin.

Installation Instructions

2.1

The image below indicates which bolts need to be removed. Pay close attention to which bolts are used to secure the taillights in place as these will be required later in the installation.



With the bolts removed the installation of the rear filler kit can begin.


Installation Instructions

3.

Rear Filler Kit Installation

With the bolts removed the installation of the rear filler kit can begin.


Start by installing the bottom filler bracket, shown in the image below.



Installation Instructions

3.1

The bottom filler bracket is installed using the bolts removed from the tailgate hinge. Push the bolts through the slot in the bottom filler bracket and fasten it down.




Installation Instructions

3.2

With the bottom bracket installed, the next step in the process is to mount the lower door frame of the canopy camper to the bottom bracket.

This is done by sliding five M8x20 hex head bolts (item 7) into the bottom frame and lining them up with the slots in the bottom support bracket. Push the bolts through the slots and fasten them loosely using a M8 Nylock nut (item 6) and washer (item 8).




Installation Instructions

3.3

With the bottom door frame installed the last part of the installation for the rear filler kit is adding the side filler boxes.


Align the M8x20 hex head bolts with the outside nut slot channel of the lower door frame and push the boxes down until they seat on the bottom bracket.



Installation Instructions

3.4



With the bottom door frame installed the last part of the installation for the rear filler kit is adding the side filler boxes. Align the M8x20 hex head bolts with the outside nut slot channel of the lower door frame and push the boxes down until they seat on the bottom bracket



Installation Instructions

3.5


With the side filler boxes in position fasten them down to the bottom filler bracket using the supplied hardware. The setup is like fitting the bottom door frame, there is just an addition of a flat washer on the inside of the box, and some plastic nut caps to finish the look off.



Installation Instructions


3.6

With the bottom filler bracket in place the next step is to slide two M8 hex nuts (item 8) into the outside nut slot of the Canopy Camper.



3.7


Next fasten the left and right brackets to the bottom filler bracket, and then to the Canopy Camper frame itself



Installation Instructions


3.8

The Install for the front filler is now complete. When installing the canopy camper on to the vehicle ensure the lip of the bottom support bracket sits over the vehicles load bin



3.9


The last step is to seal the front filler with Black UV Sikaflex as indicated below



Installation Instructions

4.

Front Filler Component Identification



Installation Instructions

4.1

Front Filler Component Identification

ITEM NO.	PART NUMBER	Revision	DESCRIPTION	QTY
1	165-GM19-CC-FNT-BOT-FIL-BRKT-01	1	FRONT BOTTOM FILLER BRACKET	1
2	165-GM19-CC-FNT-LHS-FIL-BRKT-01	0	LEFT FRONT FILLER BRKT	1
3	165-GM19-CC-FNT-RHS-FIL-BRKT-01	0	RIGHT FRONT FILLER BRKT	1
4	BHD-M8x16		M8x16 B/HD BOLT S/S	4
5	BHD-M8x20		M8x20 B/HD BOLT S/S	4
6	FFW-M8		M8x20mm OVERSIZED WASHER S/S - DIN 9021	17
7	HEX-M8x20		M8x20 HEX BOLT S/S	5
8	NCAP-M8		NUT CAP-08mm	9
9	NUT-M8		M8 HEX NUT S/S	4
10	NY-M8		M8 NYLOC NUT S/S	9
11	SW-M8		M8 SPRING WASHER S/S	4

Installation Instructions


5.

Canopy Camper Base Unit - Installation & Assembly

Seating the Base Unit

Attach the gasket material to the lower seating surface of the Canopy Camper's base frame - Refer to the stand-alone Fitment Instruction for this process.

Lower the Canopy Camper Base Unit onto the already mounted Rear Filler Assembly, as shown in the image above, and align the lower and upper portions of the door frame. Install mounting brackets to secure the camper in place.



Installation Instructions

5.1

DETAIL F SCALE 1:4

13 9 7 15

14 16 18 5 5 5 5 10 12

15 7 11 13

15 13 9 11 17 15

3

4

7

14 16 10 5 5 5 10 12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94

95

96

97

98

99

100

101

102

103

104

105

106

107

108

109

110

111

112

113

114

115

116

117

118

119

120

121

122

123

124

125

126

127

128

129

130

131

132

133

134

135

136

137

138

139

140

141

142

143

144

145

146

147

148

149

150

151

152

153

154

155

156

157

158

159

160

161

162

163

164

165

166

167

168

169

170

171

172

173

174

175

176

177

178

179

180

181

182

183

184

185

186

187

188

189

190

191

192

193

194

195

196

197

198

199

200

201

202

203

204

205

206

207

208

209

210

211

212

213

214

215

216

217

218

219

220

221

222

223

224

225

226

227

228

229

230

231

232

233

234

235

236

237

238

239

240

241

242

243

244

245

246

247

248

249

250

251

252

253

254

255

256

257

258

259

260

261

262

263

264

265

266

267

268

269

270

271

272

273

274

275

276

277

278

279

280

281

282

283

284

285

286

287

288

289

290

291

292

293

294

295

296

297

298

299

300

301

302

303

304

305

306

307

308

309

310

311

312

313

314

315

316

317

318

319

320

321

322

323

324

325

326

327

328

329

330

331

332

333

334

335

336

337

338

339

340

341

342

343

344

345

346

347

348

349

350

351

352

353

354

355

356

357

358

359

360

361

362

363

364

365

366

367

368

369

370

371

372

373

374

375

376

377

378

379

380

381

382

383

384

385

386

387

388

389

390

391

392

393

394

395

396

397

398

399

400

401

402

403

404

405

406

407

408

409

410

411

412

413

414

415

416

417

418

419

420

421

422

423

424

425

426

427

428

429

430

431

432

433

434

435

436

437

438

439

440

441

442

443

444

445

446

447

448

449

450

451

452

453

454

455

456

457

458

459

460

461

462

463

464

465

466

467

468

469

470

471

472

473

474

475

476

477

478

479

480

481

482

483

484

485

486

487

488

489

490

491

492

493

494

495

496

497

498

499

500

501

502

503

504

505

506

507

508

509

510

511

512

513

514

515

516

517

518

519

520

521

522

523

524

525

526

527

528

529

530

531

532

533

534

535

536

537

538

539

540

541

542

543

544

545

546

547

548

549

550

551

552

553

554

555

556

557

558

559

560

561

562

563

564

565

566

567

568

569

570

571

572

573

574

575

576

577

578

579

580

581

582

583

584

585

586

587

588

589

590

591

592

593

594

595

596

597

598

599

600

601

602

603

604

605

606

607

608

609

610

611

612

613

614

615

616

617

618

619

620

621

622

623

624

625

626

627

628

629

630

631

632

633

634

635

636

637

638

639

640

641

642

643

644

645

646

647

648

649

650

651

652

653

654

655

656

657

658

659

660

661

662

663

664

665

666

667

668

669

670

671

672

673

674

675

676

677

678

679

680

681

682

683

684

685

686

687

688

689

690

691

692

693

694

695

696

697

698

699

700

701

702

703

704

705

706

707

708

709

710

711

712

713

714

715

716

717

718

719

720

721

722

723

724

725

726

727

728

729

730

731

732

733

734

735

736

737

738

739

740

741

742

743

744

745

746

747

748

749

750

751

752

753

754

755

756

757

758

759

760

761

762

763

764

765

766

767

768

769

770

771

772

773

774

775

776

777

778

779

780

781

782

783

784

785

786

787

788

789

790

791

792

793

794

795

796

797

798

799

800

801

802

803

804

805

806

807

808

809

810

811

812

813

814

815

816

817

818

819

820

821

822

823

824

825

826

827

828

829

830

831

832

833

834

835

836

837

838

839

840

841

842

843

844

845

846

847

848

849

850

851

852

853

854

855

856

857

858

859

860

861

862

863

864

865

866

867

868

869

870

871

872

873

874

875

876

877

878

879

880

881

882

883

884

885

886

887

888

889

890

891

892

893

894

895

896

897

898

899

900

901

902

903

904

905

906

907

908

909

910

911

912

913

914

915

916

917

918

919

920

921

922

923

924

925

926

927

928

929

930

931

932

933

934

935

936

937

938

939

940

941

942

943

944

945

946

947

948

949

950

951

952

953

954

955

956

957

958

959

960

961

962

963

964

965

966

967

968

969

970

971

972

973

974

975

976

977

978

979

980

981

982

983

984

985

986

987

988

989

990

991

992

993

994

995

996

997

998

999

1000

1001

1002

1003

1004

1005

1006

1007

1008

1009

1010

1011

1012

1013

1014

1015

1016

1017

1018

1019

1020

1021

1022

1023

1024

1025

1026

1027

1028

1029

1030

1031

1032

1033

1034

1035

1036

1037

1038

1039

1040

1041

1042

1043

1044

1045

1046

1047

1048

1049

1050

1051

1052

1053

1054

1055

1056

1057

1058

1059

1060

1061

1062

1063

1064

1065

1066

1067

1068

1069

1070

1071

1072

1073

1074

1075

1076

1077

1078

1079

1080

1081

1082

1083

1084

1085

1086

1087

1088

1089

1090

1091

1092

1093

1094

1095

1096

1097

1098

1099

1100

1101

1102

1103

1104

1105

1106

1107

1108

1109

1110

1111

1112

1113

1114

1115

1116

1117

1118

1119

1120

1121

1122

1123

1124

1125

1126

1127

1128

1129

1130

1131

1132

1133

1134

1135

1136

1137

1138

1139

1140

1141

1142

1143

1144

1145

1146

1147

1148

1149

1150

1151

1152

1153

1154

1155

1156

1157

1158

1159

1160

1161

1162

1163

1164

1165

1166

1167

1168

1169

1170

1171

1172

1173

1174

1175

1176

1177

1178

1179

1180

1181

1182

1183

1184

1185

1186

1187

1188

1189

1190

1191

1192

1193

1194

1195

1196

1197

1198

1199

1200

1201

1202

1203

1204

1205

1206

1207

1208

1209

1210

1211

1212

1213

1214

1215

1216

1217

1218

1219

1220

1221

1222

1223

1224

1225

1226

1227

1228

1229

1230

1231

1232

1233

1234

1235

1236

1237

1238

1239

1240

1241

1242

1243

1244

1245

1246

1247

1248

1249

1250

1251

1252

1253

1254

1255

1256

1257

1258

1259

1260

1261

1262

1263

1264

1265

1266

1267

1268

1269

1270

1271

1272

1273

1274

1275

1276

1277

1278

1279

1280

1281

1282

1283

1284

1285

1286

1287

1288

1289

1290

1291

1292

1293

1294

1295

1296

1297

1298

1299

1300

1301

1302

1303

1304

1305

1306

1307

1308

1309

1310

1311

1312

1313

1314

1315

1316

1317

1318

1319

1320

1321

1322

1323

1324

1325

1326

1327

Installation Instructions

5.2

Mounting Bracket Kit - Component Identification

ITEM NO.	PART NUMBER	Revision	DESCRIPTION	QTY
1	165-GM07-CC-FNT-MNT-BRK-01	1	MOUNTING BRACKET 01	2
2	165-GM07-CC-FNT-MNT-BRK-02	0	FRONT MOUNTING BRACKET 02	4
3	165-GM07-CC-RER-MNT-BRK-01	0	MOUNT BRACKET	2
4	165-GM07-CC-RER-MNT-BRK-02	0	REAR MOUNT BRACKET GUSSET	4
5	165-GM07-CC-RER-MNT-PLT-01	0	REAR MOUNT PLATE	6
6	209-CCDC-MNT-DSC-01	0	MOUNTING DISC	6
7	209-CCDC-TOP-BRK-01	1	TOP BRACKET	2
8	BX-BB		BRACKET - BOX	1
9	FFW-M8		M8x20mm OVERSIZED WASHER S/S - DIN 9021	4
10	FW-M12		12mm FLAT WASHER (ID - 13; OD - 20; T 1.8 - 2.2) DIN - 433	4
11	FW-M8		M8x16mm FLAT WASHER S/S - DIN 125	4
12	HEX-M12x40		M12x40 HEX BOLT S/S	4
13	HEX-M8x20		M8x20 HEX BOLT S/S	6
14	NCAP-M12		NUT CAP-012mm	4
15	NCAP-M8		NUT CAP-08mm	8
16	NY-M12		M12 NYLOC NUT S/S	4
17	NY-M8		M8 NYLOC NUT S/S	6
18	FFW-M12		12mm FLAT WASHER (ID - 13; OD - 24; T 2.3-2.7) DIN - 125	4

Installation Instructions


6.

Mounting Bracket Kit - Installation

Canopy Camper Mounting Brackets

There are two different sets of brackets provided for this installation the 209-CCDC-MNT-ASSY-01 and the 165-GM07-CC-FNT-MNT-BRK-ASSY-01. The 165-GM07-CC-FNT-MNT-BRK-ASSY-01 will be used to fasten the camper down in the front and the 209-CCDC-MNT-ASSY-01 will be used to fasten the camper down in the back.


To start the installation of the mounting brackets, locate the stake holes along with the holes that go into the load bin.



Installation Instructions

6.1


The front brackets with the two slots in the top of the bracket are mounted to the bottom of the camper frame.



6.2

The rear brackets use a top mount bracket (209-CCDC-TOP-BRK-01) to fasten to the Canopy Camper Frame.

The Top bracket is secured to the frame using an M8 bolt that has been slid into the extrusion as pictured in the sliced view below.



6.3


Once all the brackets are in their correct positions they can be fastened down securely using a 13mm socket for the M8 nut and bolts and a 18 mm socket for the M12 bolts and nuts. A ratchet will also be required.

Installation Instructions

7.

Rear Door Rebate Installation

Insert the Rear Door Rebate Frame into the door frame opening, ensure that mounting holes all align. Using the supplied hardware, rivet the frame in place along the LHS, RHS and upper and lower mounting interfaces. See images below:




Installation Instructions

7.1

Rear Door Installation


The Rear Door Assembly is supplied fully assembled with its hinges, and the locking mechanism, as shown below:



Installation Instructions

7.2

Insert the assembled door into the rear door opening. Fasten the four (4) hinges into the nut slot on the RHS door frame first, using the supplied hardware. Align the two (2) locking mechanism Hook Brackets with the upper and lower lock tabs and fasten into the nut slot on the LHS frame, using the supplied hardware. Installed Rear Door shown below (rear Filler Assembly removed for clarity):



NB! The Canopy Camper must rest solely on the mounting brackets and no load is allowed on the load bin. Once this is completed, the Canopy Camper has been installed successfully.

Disclaimer

All rights reserved. No part of this website may be reproduced, translated, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without prior written permission of the owner.

Review all instructions information carefully before installation.

Any damages, direct or incidental to the installer and/or property due to incorrect installation of any parts are the responsibility of the installer. Due to the various applications and fitment options available, the responsibility lies with the user to ensure all mounting points are secure and tight before every trip.

If unsure, consult with your Distributor regarding the operations of our products.

Users are advised to be mindful of the load they are carrying and drive in accordance with road conditions.

WARNING

Always wear appropriate PPE (Personal protection equipment) when fitting our products. Although the mounting kit is designed to be DIY, if you have any doubts or concerns, contact an accredited fitment centre to carry out the work. Alu-Cab will not be liable for any injury to persons, and/or damage to products and/or vehicles.

While Alu-Cab Holdings takes reasonable measures to ensure that the contents of this Website are accurate and complete, Alu-Cab Holdings makes no representations or warranties, whether express or implied, as to the quality, timeliness, operation, integrity, availability or functionality of this Website or as to the accuracy, completeness or reliability of any information on this Website. Alu-Cab Holdings reserves the right to make changes, corrections and/or improvements to the information and to the products and programs described in such information, at any time without notice.

Alu-Cab Holdings will use reasonable endeavours to maintain the availability of the Website, except during scheduled maintenance periods, and reserves the right to discontinue providing the Website or the service or any part thereof with or without notice to you. Any person who accesses this Website or relies on this Website or on the information contained in this Website does so at his or her own risk.

Occasionally, at our discretion, we may include or offer third-party products or services on our website. These third-party sites have separate and independent privacy policies. We therefore have no responsibility or liability for the content and activities of these linked sites. Nonetheless, we seek to protect the integrity of our site and welcome any feedback about these sites.